


# Fiberglass Pole Set Assembly Instructions

Products these steps apply to:





NOTE: Keep product clear from trees, poles, buildings, or any other obstruction as it will cause premature wear.



# Display Set-Up

### Step 1

Begin by removing the parts from the carry case and placing them on a clean flat surface.

Assemble the Poles (2) together by inserting the Bottom Pole into the Middle Pole.



### Step 2

Insert the Top Pole into the Middle Pole. NOTE: for 15' and/or 17' Sail Signs you will have 2 Middle Poles to insert together before inserting the Top Pole.



### Step 3

Carefully insert the top end of the assembled Poles (2) into the pole pocket of the Fabric Graphic (1). Push the Pole (2) as far as it will go until it hits the end of the

pole pocket. DO
NOT FORCEFULLY
PUSH THE POLE
OR IT COULD
SNAP.



## Step 4


Remove the Ring (B) from the Clip (C) on the Elastic Cord Kit (3).
Connect the Ring (B) to the webbing loop on the bottom end of your Fabric Graphic Pole Pockets (1).



# Fiberglass Pole Set Assembly Instructions Cont.

### Step 6

Using the Elastic Cord (A) pull down the Fabric Graphic on the pole to create the desired shape. Knot the end of elastic Cord (A) and secure under the plastic Pole Hook located on the base of the Bottom Pole (2)




### Optional Base Scissors 4b

Place Sliver Cross Base (4b) at desired location by extending he legs outward. Insert the bottom of the Sail Sign over the Sliver Cross Base (4b) stem.



### Optional Base Spike 4a

Hammer Spike Base (4a) into the ground at desired location. **DO NOT** hammer the shorter post. Insert Bottom of Pole (2) over stem on Spike Base (4a).



### **Optional Water Ballast**

Place the Water Bag (5) over the Base (4) <u>BEFORE</u> attaching the Sail Sign. Fill Water Ballast (5) with water for stability.

NOTE 15' and 17'sails signs will need square water ballasts



## Storage and Care

Place all product parts into Carry Case and store in a cool dry location, away from direct sunlight. To clean, wipe with damp cloth. Do not iron or dry clean the banner.