



LookOurWay


GIANT INFLATABLE - INTERNAL BLOWER REPLACEMENT INSTRUCTIONS




Remove the 4 small screws on the fan's retaining cap.




Remove the retaining cap and pull out the fan.




Install the new fan.



Reinstall the fan's retaining cap



Reinstall and tighten the 4 screws



Install complete