

# LookOurWay


## INFLATABLE CASH GRAB MACHINE (CONSTANT AIR)

*Please read each step before you attempt set-up!*

### INFLATABLE CASH GRAB


**MACHINE SET UP:** Before you begin to set up your inflatable, choose a display area that is free of all obstructions (powerlines, sharp projections, etc.). The display area should be twice as large as the largest dimension of the inflatable.

1



Unpack the inflatable and place in the center of the display area.

2




Unroll the inflatable, checking that no folds exist to block the flow of the air during inflation.

Untangle all tethers and extend them from the inflatable.

Check the zippers at the base of the inflatable to be sure they are closed.

3




Stack the inflatable on top of itself so that during inflation, it will rise vertically.

Connect your Cash Blower (the bigger one) to the air inlet located in the middle of the back tube.


Connect the Inflation Blower to the air inlet beside the middle inlet.

4



Plug your Inflation Blower into a 110V outlet. Use caution when making the electrical connection. (DO NOT STAND IN WATER)

5



When fully inflated, secure all tethers to tie-down stakes placed around the inflatable so that the tethers project at a 45 degree angle.

Store accessories and bag for future use. IF YOU HAVE A PROBLEM WITH THE INFLATABLE THAT THE INSTRUCTIONS DON'T COVER, CALL FOR TROUBLESHOOTING ASSISTANCE.

(866) 586-3888

### DEFLATION

- Most inflatable can be deflated and properly stored by two people.
- To deflate, unplug the fan unit.
- Open zipper(s) and gently guide the inflatable down on top of itself, taking care not to snag it on the stakes.
- Untie tethers from tie down stakes.
- Carefully, fold the inflatable into thirds and place in the bag.

### WARNING

**WARNING: NEVER STORE YOUR INFLATABLE WET FOR OVER 48 HOURS BECAUSE MOLD AND MILDEW WILL FORM CAUSING STAINS AND DISCOLORATION. IF PACKED WET, UNPACK AND LAY OUT FLAT TO DRY FULLY IN THE SUN TO PREVENT DAMAGE. SEE WARRANTY FOR FURTHER INFORMATION.**

Remember to gather up all ground stakes and other inflatable accessories to be stored with the inflatable for the next use.