


# LookOurWay


## INFLATABLE HANGING SPHERES

1




Lay the inflatable hanging sphere flat on the ground.

2




Connect the Air Pump to the inflatable air inlet. At this point, everything should be ready for smooth and easy inflation.

3



Plug your Air Pump into a 110V outlet. Use caution when making the electrical connection. (DO NOT STAND IN WATER)

4



Once inflated, hang the inflatable hanging sphere to the preferred spot using the provided ropes set.

### DEFLATION

- Most inflatables can be deflated and properly stored by two people.
- To deflate, unplug the fan unit.
- Open zipper(s) and gently guide the inflatable down on top of itself, taking care not to snag it on the stakes.
- Untie tethers from tie down stakes
- Carefully fold the inflatable into thirds and place in the bag.

### WARNING

**WARNING:** NEVER STORE YOUR INFLATABLE WET FOR OVER 48 HOURS BECAUSE MOLD AND MILDEW WILL FORM CAUSING STAINS AND DISCOLORATION. IF PACKED WET, UNPACK AND LAY OUT FLAT TO DRY FULLY IN THE SUN TO PREVENT DAMAGE. SEE WARRANTY FOR FURTHER INFORMATION.

Remember to gather up all ground stakes and other inflatable accessories to be stored with the inflatable for the next use