



Air Dancers® Mini Inflatable Tube Man Instructions

1




Slip the stretch base of the attachment over the raised lip of the blower enclosure.

2




Ensure ample space in order to function free of obstructions.

3



Plug in.

4



Switch on.

**CUSTOMER SERVICE ISSUE? DO NOT CONTACT THE RETAILER
CONTACT US DIRECTLY FOR FASTEST AND BEST SERVICE!**

PHONE: (866) 586-3888 | EMAIL: SALES@LOOKOURWAY.COM

We can handle any customer service issue regarding this product and/or the shipment of this product from any retailer.



WARNING: Only use product in an area clear of obstructions.



WARNING: Do not use in rain or wet conditions.

- ◆ Do not block or obstruct the blower's airflow by covering the ventilation holes. These allow blower to generate sufficient airflow to effectively power the product.
- ◆ Operate only on a flat, stable, dry surface.
- ◆ Do not allow children to operate unit or play near blower.
- ◆ Do not remove screens, vents, or grill of blower.
- ◆ Do not use blower if showing damage.
- ◆ Do not alter or modify in any way or use aftermarket parts.
- ◆ Only operate from 120v North American standard outlet.
- ◆ Do not place fingers or other objects into blower.