


# Square Hanging Banner Display


## Assembly Instructions

- 1. Top Poles (8)
- 2. Bottom Poles (8)
- 3. Vertical Ribs (4)
- 4. Vertical Poles (4)
- 5. Bolts (12)
- 6. Eye Bolts (4)
- 7. Graphic




### 1 Assemble The Frame

Connect each side of the bottom (1) and top (2) tubes together to form 8 connected tubes.




### 2 Assemble The Frame

Connect the assembled bottom (1) tubes together with a straight vertical tube (4) at each corner with one of the provided bolts (5).




### 3 Assemble The Frame

Connect the curved vertical ribs (3) to the bottom frame with the provided bolts (5) at the center of each side.



### 4 Assemble The Frame

Flip the whole assembly and attach the connected top (2) tubes to the assembled curved vertical ribs (3) with the provided bolts (5).




### Storage & Care:

Store in a cool dry location. Clean hardware with a damp cloth. Machine wash the graphics in cold water on a gently cycle. Air dry only. Use a steamer for wrinkles. Never dry-clean.

# Square Hanging Banner Display


## Assembly Instructions

1. Top Poles (8)
2. Bottom Poles (8)
3. Vertical Ribs (4)
4. Vertical Poles (4)
5. Bolts (12)
6. Eye Bolts (4)
7. Graphic



### 5 Install The Graphic

Unzip your graphic (7) completely. Position the frame such that the blank back side of the graphic (7) is underneath. Ensure that the graphic is Right side up and pull it into place.




**NOTE: WHEN POSITIONING FABRIC AROUND THE FRAME, CAREFULLY LIFT AND REPOSITION.**

*DRAGGING FABRIC CAN CAUSE SNAGS.*


### 6 Install The Graphic

Secure the top of the graphic to the top of the frame by unscrewing and then feeding the eyebolt (6) through the reinforced hole in the graphic and back into the assembled frame. This will connect the top tubes (2) to each corner straight vertical tube (4). Please ensure that the eye bolts (4) are tight.



### 7 Install The Graphic

Step inside the frame, with the outside of the graphic now connected to the frame, pull the zipper to finish the graphic attachment.



### NOTES:

**Hanging Cables NOT INCLUDED.**

Most Convention Centers will require you to use their hanging hardware.

### Storage & Care:

Store in a cool dry location. Clean hardware with a damp cloth. Machine wash the graphics in cold water on a gently cycle. Air dry only. Use a steamer for wrinkles. Never dry-clean.